DYNESS

Approved Compatibility List of Inverter Brands

Low voltage battery

Inverter Brand	Inverter logo	Inverter Type	Dyness Battery Series										
			B4850	B3	A48100	B51100	BX51100	DL3.6	DL5.0	DL5.0C	DL5.0X	PowerDepot H5B	PowerBox Pro
GoodWe	GOODWE	GW3648D/5048D-ES/EM/SBP GW3K/5K-ES G2/SBP G2	√	√	√	√	√	√	√	√	√	√	√
Growatt (SANKO/Socar)	Growatt	SPF 3K~5K TL-HVM/LVM SPF 6K~12K T-HVM/DVM SPF 3K~5K ES SPH/SPA 3K~10K TL	√	√	√	√	√	√	√	√	√	√	√
Solis	solis	RHI-3K~5K-48ES RHI-3K~6K-48ES-5G S5-EH1P(3-6)-L S6-EH1P3/6K-L-EU S6-EH1P3K~8K-L-PRO DYNE 3.6L~8.0L-1P-A	√	√	√	√	√	√	√	√	√	√	√
SAJ	SAJ	H1-3K~4.6K-S2	√	√	√	√	√	√	√	√	√	√	√
SUNGROW	SUNGROW	SH3.6K~5K-30	√	√	√	√	√	√	√	√	√	√	√
DEYE	Deye 德業	SUN-3.6K~6K-SG03/04LP1-EU SUN-3.6K~8K-SG05LP1-EU SUN-5K~8K-SG01LP1-US SUN-7.6K~16K-SG01LP1-EU	√	√	√	√	√	√	√	√	√	√	√
AISHIWEI	Solplanet	ASW3K~6KH-S2	√	√	√	√	√	√	√	√	√	√	√
Luxpower	LUXPOWER	LXP Hybrid 3K~6K SNA3K~6K(Intelligent off-grid & hybrid modes)	√	√	√	√	√	√	√	√	√	√	√
MUST	MUST	PV18 2-5kW/PH182-5.5KW	√	√	√	√	√	√	√	√	√	√	√

Note: Only the inverters listed above are approved to be connected to dyness batteries.

DYNESS

Inverter Brand	Inverter logo	Inverter Type	Dyness Battery Series										
			B4850	B3	A48100	B51100	BX51100	DL3.6	DL5.0	DL5.0C	DL5.0X	PowerDepot H5B	PowerBox Pro
TBB		Kinergier Pro CK4.0S~8.0S	√	√	√	√	√	√	√	√	√	√	√
Victron		Multiplus 48V/3000~5000VA	√	√	√	√	√	√	√	√	√	√	√
IMEON		IMEON 3.6~9.12	√	√	√	√	√	√	√	√	√	√	√
SMA		SI4.4M /6.0H/8.0H-12	√	√	√	√	√	√	√	√	√	√	√
DELIOS		DLS-300C/DLS-450C/DLS-600C	√	√	√	√	√	√	√	√	√	√	√
Studer Innotec		Xtender 48V serie VarioString serie Vario Track 48V serie	√	√	√	√	√	√	√	√	√	√	√
Sorotec		REVO II 3.2K~5.5K-48	√	√	√	√	√	√	√	√	√	√	√
SERMATEC		SMT-5K-TL-LV	√	√	√	√	√	√	√	√	√	√	√
SOFAR		HYD 3K~6K-ES	√	√	√	√	√	√	√	√	√	√	√
INFINI /VOLTRONIC		Infinisolar series 48V /Axpert-King series48V with communication Card (Power frequency)	√	√	√	√	√	√	√	√	√	√	√
INFINI /VOLTRONIC (MERCER)		Axpert-King MKS Modbus Duo Box /Axpert-King VM (RS485 PN-protocol) ICC											
MAGAREVO		R3K~6KL1	√	√	√	√	√	√	√	√	√	√	√
SUNRAY		MPS series 1/3/5kva	√	√	√	√	√	√	√	√	√	√	√
GMDE		5200TL series	√	√	√	√	√	√	√	√	√	√	√
Ingeteam		INGECON SUN STORAGE 3TL~6TLM											

Inverter Brand	Inverter logo	Inverter Type	Dyness Battery Series										
			B4850	B3	A48100	B51100	BX51100	DL3.6	DL5.0	DL5.0C	DL5.0X	PowerDepot H5B	PowerBox Pro
Hoymiles		HYS-LV-EUG1 Series HYS-LV-USG1 Series	√	√	√	√	√	√	√	√	√	√	√
Afore		AF3K~6K-SL AF1K~3.6K-SL-1	√	√	√	√	√	√	√	√	√	√	√
Amensolar		N3H-X5.0~8.0-US	√	√	√	√	√	√	√	√	√	√	√
Senergy		SE 4K6~6KHB-60/120 SE 4K6~6KAC	√	√	√	√	√	√	√	√	√	√	√
LIVOLTEK		GF1-3K~5K48S1	√	√	√	√	√	√	√	√	√	√	√
TSUN		TSOL-H3.0K~6K-H	√	√	√	√	√	√	√	√	√	√	√
HYPDNTECH		HES-3~6KW	√	√	√	√	√	√	√	√	√	√	√
Steca		Solarix PLI 5000-48	√	√	√	√	√	√	√	√	√	√	√
Schneider		Conext Series Products/ Conext XW Pro	√	√	√	√	√	√	√	√	√	√	√
SRNE		HT4830~4840S60 HT4850S80 ASF4880U180-H ASF48100U200-H	√	√	√	√	√	√	√	√	√	√	√

Note: Only the inverters listed above are approved to be connected to dyness batteries.

Low voltage battery-12V

Inverter Brand	Inverter logo	Inverter Type	Dyness Battery Series	
			RV12100	RV12200
Steca		Steca Solarix PI 550~1000-12	√	√
MUST		PV18-1012 VPK/VPM EP18-1012	√	√
Victron		MultiPlus C12/1200~2000 MultiPlus 12/3000	√	√

Low voltage battery-24V

Inverter Brand	Inverter logo	Inverter Type	Dyness Battery Series
			B25100
Steca		Steca Solarix PI 550~2400-24	√
Sorotec		REVO VM II 3.0kW-24	√
Victron		MultiPlus 24/3000~5000	√
Growatt (SANKO/Socar)		SPF 2K~3KTL HVM-24	√
MUST		PV18-2024~3024 VHM\VPK\VPM\LHM、 PV18-3024 Pro EP18-2024~3024 PV18-1024~2524 LHM PH18-2024~3024 PLUS PH18-3024 Pro	√

Note: Only the inverters listed above are approved to be connected to dyness batteries.

High voltage battery

Inverter Brand	Inverter logo	Inverter Type	Dyness Battery Series				
			PowerRack HV2	PwerRack HV4	PwerRack HV4F	Tower Series	Tower Pro Series
Goodwe	GOODWE	GW3K/5K/6K/10K-EH/ET EHB GW40-50K-ET-10	√	√	√	√	√
Growatt	Growatt	SPH 10000TL3 BH/SPA4000 WIT 50-100K	√	√	√	√	√
SERMATEC	SERMATEC	SMT-10K-TL-TH	√	√	√	√	√
ATESS	ATESS	HPS 5000/7500/10000TLS HPS 30/50/100/120/150	√	√	√	√	√
Solis	solis	RHI-3P(5-10)K-HVES-5G RHI-1P7.6K-HVES-5G S6-EH3P10K-H(PRO) S6-EH1P(3.8-11.4)K-H-US S6-EH3P(5-10)K2-H S6-EH3P30-50K-H	√	√	√	√	√
Hoymiles	hoymiles	HY3 Series/HYT-10.0HV-EUGI	√	√	√	√	√
Ecactus	ECACTUS	WH-SPA-3.6H/WH-SPA-5.0H	√	√	√	√	√
Sinexcel	Sinexcel	PWS1-50K/PWG2-100K	√	√	√	√	√
Sunways	sunways	STH-4K~12KTL-HT-P STH-12KTL-HT-CN	√	√	√	√	√
Thinkpower	Thinkpower	EPH12KTL	√	√	√	√	√
HYPONTECH	HYPONTECH	HHS-3680/5000 HHT-5K-12K	√	√	√	√	√
SAJ	SAJ	H2-5K/6K/8K/10-T2	√	√	√	√	√
Bluesun	BLUESUN	BSE12KH1NA	√	√	√	√	√
DEYE	Deye 德业	SUN-6-20K-SG01HP3-EU-AM2 SUN-50K-SG01HP3-EU-BM4	√	√	√	√	√

Inverter Brand	Inverter logo	Inverter Type	Dyness Battery Series				
			PowerRack HV2	PwerRack HV4	PwerRack HV4F	Tower Series	Tower Pro Series
MEGAREVO		RKH1/RKH3	√	√	√	√	√
LUXPOWER		LXP-PCS6T	√	√	√	√	√
Ingeteam		INGECON SUN STORAGE1 PLAY TL M 3-6kW INGECON SUN STORAGE 100TL	√	√	√	√	√
KOYOE		KY-EST-10KH	√	√	√	√	√
MEGAREVO		MEGA0100TS	√	√	√	√	√
SOLINTEG		MHT-4~12K-25/MHT-10~20K-40 MHS-3~8K-30	√	√	√	√	√
AISHIWEI		ASW08KH-T1/ASW10KH-T1/ASW12KH-T1	√	√	√	√	√
Afore		AF3K/9.6K-DH AF3K/30K-TH	√	√	√	√	√
SINENG		SN-3.0/3.6/4.0/5.0/6.0HS	√	√	√	√	√
Autarco		S2.LH(5000-10000) S2.LH(5000-10000)-MII	√	√	√	√	√
KOSTAL		PLENTICORE plus 3.0~10 PLENTICORE plus-G2 3.0~10	√	√	√	√	√
TSUN		TSOL-H Series	√	√	√	√	√

Note: This high voltage list covers all Dyness energy storage prodducts. The specific type of high-voltage batteries that the invertercan be connected to are listed in the appendix.
The HV series single cluster supports up to 16 modulesin series, If the customer has a customized project, please communicate with our pre-sales technical support in advance to confirm
Only the inverters listed above are approved to be cornnected to dyness batteries.

➢ **Goodwe Inverter**

Battery Series	Battery Model	Inverter Series				
		Goodwe				
		GW5K~10 K-ET	BT (5K~10K)	EH (3K~6K)	BH (3K~6K)	EHB
Tower	T-7			√	√	√
	T-10	√	√	√	√	√
	T-14	√	√	√	√	√
	T-17	√	√			
Tower Pro	TP-7			√	√	√
	TP-11	√	√	√	√	√
	TP-15	√	√	√	√	√
	TP-19	√	√			
HV2	HV2-4S			√	√	√
	HV2-5S	√	√	√	√	√
	HV2-6S	√	√	√	√	√
	HV2-7S	√	√	√	√	√
	HV2-8S	√	√	√	√	√
	HV2-9S	√	√			
	HV2-10S	√	√			
	HV2-11S	√	√			
HV4	HV4-4S			√	√	√
	HV4-5S	√	√	√	√	√
	HV4-6S	√	√	√	√	√
	HV4-7S	√	√	√	√	√
	HV4-8S	√	√			
	HV4-9S	√	√			
	HV4-10S	√	√			
HV4F/ Powerstone	HV4F-7S	√	√	√	√	√
	HV4F-8S	√	√			
	HV4F-9S	√	√			
	HV4F-10S	√	√			

Powerstone is the outdoor cabinet form of HV4F, with the same voltage platform and battery capacity, so the specifications on the compatibility list are also the same.

➢ Growatt、Ecactus、Bluesun Inverter

Battery Series	Battery Model	Inverter Series				
		Growatt		Ecactus		Bluesun
		SPH4K~10K TL3 BH	SPA 4K~10K	WH-SPA-3.6/5.0H	WH-SHC 362~602	BSE12K H1NA
Tower	T-7	√	√	√	√	√
	T-10	√	√	√	√	√
	T-14	√	√	√	√	
	T-17	√	√			
Tower Pro	TP-7	√	√	√	√	√
	TP-11	√	√	√	√	√
	TP-15	√	√	√	√	
	TP-19	√	√			
HV2	HV2-4S	√	√	√	√	√
	HV2-5S	√	√	√	√	√
	HV2-6S	√	√	√	√	√
	HV2-7S	√	√	√	√	√
	HV2-8S	√	√	√	√	
	HV2-9S	√	√		√	
	HV2-10S	√	√			
HV4	HV4-4S	√	√	√	√	√
	HV4-5S	√	√	√	√	√
	HV4-6S	√	√	√	√	√
	HV4-7S	√	√	√	√	√
	HV4-8S	√	√		√	
	HV4-9S	√	√			
HV4F/ Powerstone	HV4F-7S	√	√	√	√	
	HV4F-8S	√	√		√	
	HV4F-9S	√	√			

➢ Hoymiles、SAJ Inverter

Battery Series	Battery Model	Inverter Series				
		Hoymiles			SAJ	
		HY3 5K~ 10K HV	HYT-5.0~ 12.0HV-EUG1	HAT-5.0~ 10.0HV-EUG1	H2-5K~ 10K-T2	H2-3K~ 6K-S2
Tower	T-7	√				√
	T-10	√	√	√	√	√
	T-14	√	√	√	√	√
	T-17		√	√	√	
TowerPro	TP-7	√				√
	TP-11	√	√	√	√	√
	TP-15	√	√	√	√	√
	TP-19		√	√	√	
HV2	HV2-4S	√				√
	HV2-5S	√	√	√	√	√
	HV2-6S	√	√	√	√	√
	HV2-7S	√	√	√	√	√
	HV2-8S	√	√	√	√	√
	HV2-9S	√	√	√	√	
	HV2-10S		√	√	√	
	HV2-11S		√	√	√	
HV4	HV4-4S	√	√	√		√
	HV4-5S	√	√	√	√	√
	HV4-6S	√	√	√	√	√
	HV4-7S	√	√	√	√	√
	HV4-8S	√	√	√	√	
	HV4-9S		√	√	√	
	HV4-10S		√	√	√	
HV4F	HV4F-7S	√	√	√	√	√
	HV4F-8S	√	√	√	√	
	HV4F-9S		√	√	√	
	HV4F-10S		√	√	√	

➢ SERMATEC、ATESS、Sunways Inverter

Battery Series	Battery Model	Inverter Series				
		SERMATEC	ATESS		Sunways	
		SMT-10K -TL-TH	HPS 5K-10K TL	HPS 30~150	STH-4~12 KTL-HT -P(CN)	STH - 3~8K TL-HS
Tower	T-7					√
	T-10	√			√	√
	T-14	√	√		√	√
	T-17	√	√	√	√	
	T-21	√	√	√	√	
Tower Pro	TP-7					√
	TP-11	√			√	√
	TP-15	√	√		√	√
	TP-19	√	√	√	√	
	TP-23	√	√	√	√	
HV2	HV2-4S					√
	HV2-5S	√			√	√
	HV2-6S	√			√	√
	HV2-7S	√	√		√	√
	HV2-8S	√	√		√	√
	HV2-9S	√	√	√	√	√
	HV2-10S	√	√	√	√	
	HV2-11S	√	√	√	√	
HV4	HV4-4S	√			√	√
	HV4-5S	√			√	√
	HV4-6S	√			√	√
	HV4-7S	√	√		√	√
	HV4-8S	√	√	√	√	√
	HV4-9S	√	√	√	√	
	HV4-10S	√	√	√	√	
	HV4-11S	√	√		√	
HV4F/ Powerstone	HV4F-7S	√	√		√	√
	HV4F-8S	√	√	√	√	√
	HV4F-9S	√	√	√	√	
	HV4F-10S	√	√	√	√	
	HV4F-11S	√	√		√	

➢ Solis Inverter

Battery Series	Battery Model	Inverter Series				
		Solis				
		RHI-3P(5-10)K-HVES-5G	RHI-1P7.6K-HVES-5G	S6-EH3P 10K-H (PRO)	S6-EH3P (5-10)K2-H(EU)	S6-EH1P (3.8-11.4)K-H-US
Tower	T-7	√	√	√	√	√
	T-10	√	√	√	√	√
	T-14	√	√	√	√	√
	T-17	√		√	√	
TowerPro	TP-7	√	√	√	√	√
	TP-11	√	√	√	√	√
	TP-15	√	√	√	√	√
	TP-19	√		√	√	
HV2	HV2-4S	√	√	√	√	√
	HV2-5S	√	√	√	√	√
	HV2-6S	√	√	√	√	√
	HV2-7S	√	√	√	√	√
	HV2-8S	√	√	√	√	√
	HV2-9S	√	√	√	√	√
	HV2-10S	√		√	√	
	HV2-11S	√		√	√	
HV4	HV4-4S	√	√	√	√	√
	HV4-5S	√	√	√	√	√
	HV4-6S	√	√	√	√	√
	HV4-7S	√	√	√	√	√
	HV4-8S	√	√	√	√	√
	HV4-9S	√		√	√	
	HV4-10S	√		√	√	
HV4F	HV4F-7S	√	√	√	√	√
	HV4F-8S	√	√	√	√	√
	HV4F-9S	√		√	√	
	HV4F-10S	√		√	√	

➢ **Solplanet、HYPONTECH、Thinkpower Inverter**

Battery Series	Battery Model	Inverter Series				
		Solplanet		HYPONTECH		Thinkpower
		ASW08 ~12K H-T1	ASW08 ~12K H-T3	HHS-3680/5000	HHT-5K-12K	EPH 4K~12K TL
Tower	T-7	√	√	√		
	T-10	√	√	√	√	√
	T-14	√	√	√	√	√
	T-17	√	√		√	√
	T-21				√	√
TowerPro	TP-7	√	√	√		
	TP-11	√	√	√	√	√
	TP-15	√	√	√	√	√
	TP-19	√	√		√	√
	TP-21				√	√
HV2	HV2-4S	√	√	√		
	HV2-5S	√	√	√	√	√
	HV2-6S	√	√	√	√	√
	HV2-7S	√	√	√	√	√
	HV2-8S	√	√	√	√	√
	HV2-9S	√	√	√	√	√
	HV2-10S	√	√		√	√
	HV2-11S	√	√		√	√
HV4	HV4-4S	√	√	√	√	√
	HV4-5S	√	√	√	√	√
	HV4-6S	√	√	√	√	√
	HV4-7S	√	√	√	√	√
	HV4-8S	√	√	√	√	√
	HV4-9S	√	√		√	√
	HV4-10S	√	√		√	√
	HV4-11S				√	√
HV4F	HV4F-7S	√	√	√	√	√
	HV4F-8S	√	√	√	√	√
	HV4F-9S	√	√		√	√
	HV4F-10S	√	√		√	√
	HV4F-11S				√	√

➢ **SOLINTEG Inverter**

Battery Series	Battery Model	Inverter Series			
		SOLINTEG			
		MHT-25~50K-100	MHT-4K~12K-25	MHT-10K~20K-40	MHS-3K~8K-30
Tower	T-7	√	√	√	√
	T-10	√	√	√	√
	T-14	√	√	√	√
	T-17	√	√	√	
	T-21	√	√	√	
TowerPro	TP-7	√	√	√	√
	TP-11	√	√	√	√
	TP-15	√	√	√	√
	TP-19	√	√	√	
	TP-21	√	√	√	
HV2	HV2-4S	√	√	√	√
	HV2-5S	√	√	√	√
	HV2-6S	√	√	√	√
	HV2-7S	√	√	√	√
	HV2-8S	√	√	√	√
	HV2-9S	√	√	√	
	HV2-10S	√	√	√	
	HV2-11S	√	√	√	
HV4	HV4-4S	√	√	√	√
	HV4-5S	√	√	√	√
	HV4-6S	√	√	√	√
	HV4-7S	√	√	√	√
	HV4-8S	√	√	√	√
	HV4-9S	√	√	√	
	HV4-10S	√	√	√	
	HV4-11S	√	√	√	
HV4F	HV4F-7S	√	√	√	√
	HV4F-8S	√	√	√	√
	HV4F-9S	√	√	√	
	HV4F-10S	√	√	√	
	HV4F-11S	√	√	√	

➢ **Deye、Afore、KOYOE Inverter**

Battery Series	Battery Model	Inverter Series					
		Deye		Afore		KOYOE	
		SUN-6K~15K-SG01HP3-EU-AM2	SUN-25~50K-SG01HP3-EU-BM2/3/4	AF3K~9.6K-DH	AF3K~30K-TH	KY-EST-6K~10KH	KY-EST-12~20KH
Tower	T-7	√	√	√	√		
	T-10	√	√	√	√	√	√
	T-14	√	√	√	√	√	√
	T-17	√	√		√	√	√
	T-21	√	√		√		√
TowerPro	TP-7	√	√	√	√		
	TP-11	√	√	√	√	√	√
	TP-15	√	√	√	√	√	√
	TP-19	√	√		√	√	√
	TP-21	√	√		√		√
HV2	HV2-4S	√	√	√	√		
	HV2-5S	√	√	√	√	√	√
	HV2-6S	√	√	√	√	√	√
	HV2-7S	√	√	√	√	√	√
	HV2-8S	√	√	√	√	√	√
	HV2-9S	√	√	√	√	√	√
	HV2-10S	√	√		√	√	√
	HV2-11S	√	√		√		√
HV4	HV4-4S	√	√	√	√	√	√
	HV4-5S	√	√	√	√	√	√
	HV4-6S	√	√	√	√	√	√
	HV4-7S	√	√	√	√	√	√
	HV4-8S	√	√	√	√	√	√
	HV4-9S	√	√		√	√	√
	HV4-10S	√	√		√		√
	HV4-11S	√	√		√		√
HV4F	HV4F-7S	√	√	√	√	√	√
	HV4F-8S	√	√	√	√	√	√
	HV4F-9S	√	√		√	√	√
	HV4F-10S	√	√		√		√
	HV4F-11S	√	√		√		√

➢ **Kostal Inverter**

Battery Series	Battery Model	Inverter Series			
		Kostal			
		PLENTICORE plus 3.0~10	PLENTICORE plus-G2 3.0~10	PLENTICORE BI 5.5/10-26	PLENTICORE BI-G2 5.5/10-26
Tower	T-7	√	√	√	√
	T-10	√	√	√	√
	T-14	√	√	√	√
	T-17	√	√	√	√
TowerPro	TP-7	√	√	√	√
	TP-11	√	√	√	√
	TP-15	√	√	√	√
	TP-19	√	√	√	√

➢ Autarco、RENAC、Hopewind、SINENG Inverter

Battery Series	Battery Model	Inverter Series				
		Aurarco		RENAC	Hopewind	SINENG
		S2.LH 5K~10K	LH5K~ 10K-MII	N3-HV -5.0~10.0	HYNV5~ 12K-G01	SN-3.0~ 6.0HS
Tower	T-7	√	√	√	√	√
	T-10	√	√	√	√	√
	T-14	√	√	√	√	√
	T-17	√	√	√	√	
	T-21			√	√	
TowerPro	TP-7	√	√	√	√	√
	TP-11	√	√	√	√	√
	TP-15	√	√	√	√	√
	TP-19	√	√	√	√	
	TP-21			√	√	
HV2	HV2-4S	√	√	√	√	√
	HV2-5S	√	√	√	√	√
	HV2-6S	√	√	√	√	√
	HV2-7S	√	√	√	√	√
	HV2-8S	√	√	√	√	√
	HV2-9S	√	√	√	√	
	HV2-10S	√	√	√	√	
	HV2-11S	√	√	√	√	
HV4	HV4-4S	√	√	√	√	√
	HV4-5S	√	√	√	√	√
	HV4-6S	√	√	√	√	√
	HV4-7S	√	√	√	√	√
	HV4-8S	√	√	√	√	√
	HV4-9S	√	√	√	√	
	HV4-10S	√	√	√	√	
	HV4-11S			√	√	
HV4F	HV4F-7S	√	√	√	√	√
	HV4F-8S	√	√	√	√	√
	HV4F-9S	√	√	√	√	
	HV4F-10S	√	√	√	√	
	HV4F-11S			√	√	

➢ **Sinexcel、Ingeteam 、MAGAREVO Inverter**

Battery Series	Battery Model	Inverter Series						
		Sinexcel		Ingeteam		MEGAREVO		
		PWG2-50K/100K-CN	PWS1-150~250K	INGECON SUN STORAGE1 PLAY TL M 3~6 kW	INGECON SUN STORAGE 100TL	R5K~11K4 H1	R6K~12K H3	MEGA0100TS
Tower	T-7			√		√	√	
	T-10	√		√		√	√	
	T-14	√		√			√	
	T-17						√	√
	T-21		√					√
Tower Pro	TP-7			√		√	√	
	TP-11	√		√		√	√	
	TP-15	√		√			√	
	TP-19						√	√
	TP-21		√					√
HV2	HV2-4S			√		√	√	√
	HV2-5S			√		√	√	√
	HV2-6S	√		√		√	√	√
	HV2-7S	√		√		√	√	√
	HV2-8S	√		√			√	√
	HV2-9S	√					√	√
	HV2-10S						√	√
	HV2-11S						√	√
	HV2-12S		√					
	HV2-13S		√					
	HV2-14S		√		√			
	HV2-15S		√		√			
HV4	HV4-4S			√		√	√	√
	HV4-5S			√		√	√	√
	HV4-6S	√		√		√	√	√
	HV4-7S	√		√		√	√	√
	HV4-8S	√					√	√
	HV4-9S	√					√	
	HV4-10S						√	
	HV4-11S							
	HV4-12S							
	HV4-13S				√			
	HV4-14S				√			
HV4F/ Powerstone	HV4F-7S	√		√		√	√	
	HV4F-8S	√					√	
	HV4F-9S	√					√	
	HV4F-10S						√	
	HV4F-11S							
	HV4F-12S							

	HV4F-13S				√			
	HV4F-14S				√			

➢ **Solis、Goodwe、Growatt Inverter**

Battery Series	Battery Model	Inverter Series		
		Solis	Goodwe	Growatt
		S6-EH3P30-50K-H	GW40-50K-ET-10	WIT 50-100K
Tower	T-7	√		
	T-10	√	√	
	T-14	√	√	
	T-17	√	√	
	T-21	√	√	
Tower Pro	TP-7	√		
	TP-11	√	√	
	TP-15	√	√	
	TP-19	√	√	
	TP-21	√	√	
HV2	HV2-4S	√		
	HV2-5S	√	√	
	HV2-6S	√	√	
	HV2-7S	√	√	
	HV2-8S	√	√	
	HV2-9S	√	√	
	HV2-10S	√	√	
	HV2-11S	√	√	
	HV2-12S	√	√	
	HV2-13S	√	√	
	HV2-14S	√	√	
	HV2-15S	√	√	√
HV4	HV4-4S	√		
	HV4-5S	√	√	
	HV4-6S	√	√	
	HV4-7S	√	√	
	HV4-8S	√	√	
	HV4-9S	√	√	
	HV4-10S	√	√	
	HV4-11S	√	√	
	HV4-12S	√	√	
	HV4-13S	√	√	
	HV4-14S	√	√	√
	HV4-15S			√
HV4F/ Powerstone	HV4F-7S	√	√	
	HV4F-8S	√	√	
	HV4F-9S	√	√	
	HV4F-10S	√	√	
	HV4F-11S	√	√	
	HV4F-12S	√	√	
	HV4F-13S	√	√	

	HV4F-14S	√	√	√
	HV4F-15S			√